


CHANNELS 0 THRU 7



CHANNELS 8 THRU 15

20 1 2 22 2 19 24 3 4 26 25 23 28 5 6 30 29 21 32 7 8 34 33 3 30 9 10 36 37 30 40 11 12 42 41 39 44 13 14 46 45 43 48 15 17